

### IMPORTANT


This quick guide illustrates the steps to follow to enroll your appliance on the App **Rosières E-Picurien**, using a device with Bluetooth 4.0 (or higher) technology. In this case, the procedure is simplified and faster (Easy Enrollment).

If you are using a device without Bluetooth technology (or less than 4.0), please follow the instructions described on the other side of this guide.

Download the App !



### 01 START



Mark down the appliance Serial Number (with the help of the image above).


Mark down the Wi-Fi Name and Password (WPA/WEP Key) which are normally placed on the back of your Wi-Fi router.

**NOTE** – The frequency of the home Wi-Fi network has to be set on the 2.4 GHz band. You cannot configure the appliance if your home network is set to the 5 GHz band.

**NOTE** – If you are having trouble locating the WPA/WEP Password, please contact your Internet Provider.

Please make sure your smartphone is connected to the same Wi-Fi network and has the Bluetooth enabled within the “Settings”. Refer to the manual for more details.

### 02




Download the **Rosières E-Picurien** App from the Store.

Open the **Rosières E-Picurien** App and create your user profile by tapping on “Register”. Accept the privacy policy and fill in the required fields.

**NOTE** – The App is available for Android (version 4.4 or higher) and iOS (version 8.0 or higher) devices.


**NOTE** – If you already have a **Rosières E-Picurien** user profile, you can login using your credentials.

### 03




In the homepage, tap on the icon with the three bars on the top left to enter your profile, then tap on “REGISTER NEW APPLIANCE” and select the name of the product that you want to enroll.

### 04



Insert the purchase date of your appliance (DD/MM/YYYY), then tap on “Proceed”.

### 05



Insert the 16 digits of the serial number or scan the QR code on the appliance helping you with the image above. Tap on “Next”. Check data correctness of the data and tap on “Confirm”. Once the system has recognized the product, tap on “Next”.

### 06




1) Tap on the icon

### 07



2) Press and hold the One-Fi icon for 3 seconds



Insert the password of your home Wi-Fi network.

Select the type of password (WEP or WPA), then tap on “Confirm”.


**The enrollment process is now finished.**

**NOTE** – If this is not automatically synchronised by the App, please insert the name of your home Wi-Fi network in the first box; pay attention to the difference between lowercase and uppercase.



### IF THE SET UP IS NOT SUCCESSFUL

It's important to establish a good Wi-Fi signal strength between the home router and the appliance: low Wi-Fi signal strength would cause the failure of the final stage of the set up. To assess if this is the case, start the connection process again from Step 1; when you get to Step 6, when you get to Step 6, place your device (smartphone or tablet) next to the router and search for “WIFIOVEN-xyzk” net generated by the appliance. If this does not come up as an option, it means that the router cannot see the appliance. In this case, we highly recommend you to bring the router near the appliance (if possible) or contact your internet provider to purchase a compatible “Wi-Fi Range Extender” to increase the signal strength.


### Remote control mode



Tap on One-Fi icon



3) Click the “OK” of Easy Enrollment



**In App** - Tap on “Confirm”. Wait for APP to connect to the appliance.

**NOTE** – Enrollment must be completed within 5 minutes.

**NOTE** – In case of any issue, tap “Retry”, making sure you have enabled Bluetooth on your device (smartphone / tablet). If the process has not been completed correctly yet, tap on “Proceed with Standard Enrollment”.

**NOTE** – To ensure correct data transfer, we recommend you to stay with the device close to the appliance.

END




### IMPORTANT

This quick guide outlines the steps you should follow to enroll your appliance using the App **Rosières E-Picurien**, utilizing a device without Bluetooth technology. We recommend you to proceed with a smartphone/tablet equipped with this technology to make the procedure simpler.

If you are using a device with Bluetooth technology (or higher than 4.0), please follow the instructions described on the other side of this guide.

Download the App !




Make a note of the appliance Serial Number (with the help of the image above) and Wi-Fi Name and Password (WPA/WEP Key), which are normally found on the back of your Wi-Fi router.

Please make sure that your smartphone/tablet is connected to the same Wi-Fi network.

**NOTE** – The frequency of the home Wi-Fi network has to be set on the 2.4 GHz band. You can not configure the appliance if your home network is set to the 5 GHz band.

**NOTE** – If you are having trouble locating the WPA/WEP Password, please contact your Internet Provider.




Download the **Rosières E-Picurien** App from the Store.


Open the **Rosières E-Picurien** App and create your user profile by tapping on **“Register”**. Accept the privacy policy and fill in the required fields.

**NOTE** – The App is available for Android (version 4.4 or higher) and iOS (version 8.0 or higher) devices.

**NOTE** – If you already have a **Rosières E-Picurien** user profile, you can login using your credentials.



In the homepage, tap on the icon with the three bars on the top left to enter your profile, then tap on **“REGISTER NEW APPLIANCE”** and select the name of the product that you want to enroll.




Insert the purchase date of your appliance (DD/MM/YYYY), then tap on **“Proceed”**.

Insert the 16 digits of the serial number or scan the QR code on the appliance. Tap on **“Next”**. Check data correctness and tap on **“Confirm”**. Once the system has recognized the product, tap on **“Next”**.



1) Tap on the icon

2) Press and hold the One-Fi icon for 3 seconds




3) Click the “OK” of Standard Enrollment

**In App** - Tap on **“Confirm”**.

**NOTE** – Enrollment must be completed within 5 minutes.

**NOTE** – To ensure correct data transfer, we recommend that you stay with the device close to the appliance.




Exit the **Rosières E-Picurien** App.

Go to your device Wi-Fi settings.



In the list of available Wi-Fi networks, select **“WIFIOVEN-xyzk”**.


**NOTE** – If you do not find it, wait few more seconds or proceed with a new scan.



Exit from the settings of your device.

Return to the **Rosières E-Picurien** App and wait for the App to detect the appliance.


Once the **“Wi-Fi Network is active”** screen appears, tap on **“Next”**.



Insert the password of your home Wi-Fi network.

Select the type of password (WEP or WPA), then tap on **“Confirm”**.

**NOTE** – If this is not automatically synchronised by the App, please insert the name of your home Wi-Fi network in the first box; pay attention to the difference between lowercase and uppercase.




Wait until the end of the data transfer process between the App and the product, then tap on **“Confirm”**. **“CONNECTED”** appears on the appliance display and then **“REMOTE CONTROL ON”**.

The enrollment process is now finished.


END

### IF THE SET UP IS NOT SUCCESSFUL

It's important to establish a good Wi-Fi signal strength between the home router and the appliance: low Wi-Fi signal strength would cause the failure of the final stage of the set up. To assess if this is the case, start the connection process again from Step 1; when you get to Step 5, place your device (smartphone or tablet) next to the router and search for **“WIFIOVEN-xyzk”** net generated by the appliance. If this does not come up as an option, it means that the router cannot see the appliance. In this case, we highly recommend you to bring the router near the appliance (if possible) or contact your internet provider to purchase a compatible **“Wi-Fi Range Extender”** to increase the signal strength.



Tap on One-Fi icon



To stop any cooking in progress please turn off remote control mode

